

Introduction

QC-CALC Real-Time is used to collect and display measurement results from all CMMs, Video CMMs, and hand gages without operator intervention. Reports can be created and data can be exported to spreadsheets, databases, and other SPC programs. This means you can transfer data from all of your measurement devices to any SPC package using one program!

Our goal is to make data collection seamless regardless of the equipment purchased or software used.

Key Benefits

- Fully automatic data collection from over 200 types of machines
- View up to 1200 live plots (characteristics) while collecting data for many more
- Manual and automatic export capability to over 40 different output formats
- Manual and automatic report generation
- 21 CFR Part 11 compliance
- Trend detection with email alerts
- Dynamic filtering of characteristics
- Multiple gage output combined into one screen (MultiSource)
- True Position Charting with 2D position charts
- Flexible plots support I&MR, XBar & Range, Scatter, Whisker, and True Position Plots



Pinpoint On-Screen Information

The plots are interactive and can be interrogated for information and statistics using the mouse to target specific or multiple points.

Trend Analysis

The process can be monitored and reports automatically triggered as trends in the data occur. Operators can then be forced to assign causes and corrective actions.

Quick Stats

Calculations are updated in the Quick Stats panel instantly as points are highlighted and as the mouse moves from plot to plot.

Exporting

Data can be exported either manually or automatically by part interval to over 40 different output formats.

Reporting

Reports can be printed either manually or automatically by part interval or by exception event. Reports can be printed to the printer, preview, or any of several output file formats such as PDF. Reports can also easily be attached to emails allowing QC-CALC to notify the appropriate personnel when the process moves outside control, specification, or configurable limits.

Manual Input Screen

In addition to data collected from automatic inspection equipment, QC-CALC can prompt inspectors for additional measurements or trace data not available from the gage.

Assignable Causes

Indicate assignable cause variance by right-clicking on the plots and assigning a cause to your part.




Record Filtering

Quickly display and report on the data needed at the moment. Dynamic record filtering allows the filter to change automatically based on the part or user input just received.

Live True Position Charts

Relationships can be created between the X, Y, Diameter, and True Position data coming from the inspection equipment to create a stacked true position plot. This unique chart depicts the true position with calculated MMC bonus in the top half and the 2D position relative to specification limits in the bottom half. The Cpk and centroid are also calculated and displayed for informational purposes.



Gage R&R Wizard


Inspection data is useless without first proving the reliability of the measurement system being used. A Gage Repeatability and Reproducibility (GR&R) study doesn't have to be a painful process. QC-CALC's Gage R&R Wizard guides users through the setup process, warns of potential problems, and analyzes the results via customizable reports.

	Gage R&R Anova	using Percent	t of Spec Limits	January 16, 2009 1:46:27 p
Prolink				
Gage Type: CMM Large Gage Size: 12x12x24 Gage Number: 432	Blue machine Perfo Reco	med by Bill and E rd Range: 1 - 90	bab	Parts 10 Trials 3 Operators 3 Total Records 90
wordd be writen ain rhenal Part Va Researchallita (FV) Researchallita (FV) Researchallita (FV) Researchall (rmohille process is actually upving. Fan infolge meaners uppart load Gelp 2007 [3:13 uppart) den met. The actual courts, ordy in relational of how much the page nearbys very when the same actual uppart of the page nearbys with the same means an uppart of the same means of the same when a uppart of the same means and the same means of the same when a uppart of the same means and the same means of the same same and the same means of the	the parts the geging stop percentage of 1 total variation to and the posses operator is smaller and spoter catter of interpretation; mitigraphic Sciff Tot. 0, 1916	Instaure of the contribute variation of Repeatabilities are as opposed to the inner interfacting process descense, in the more important "avairing" Bay () as the later of a second process and the second and the advected of a second with the integra of month for author interfaction of loss of control. The second process are as a second with the month of a second process of the month of a second process of the month of a second process of the more second process of the Representation.	y and Reproducibility caused by This number, expressed as a RBR is a large percentage of gaps and the process are good in transmit the process separat from percebs gaps would allow a following table shows typical
CMM or Vision inspection syste checked if this value is high.	Gag	je R & R (Range)	Report January 16, 200	2009 7.34 p
Dimension Dimension 1 Orce danseler 2 Orcie X 8 Orce Y	Proletik Part No. & Name: Sample Gage R&R_GERI QC Characteristics: Carcle dameter Namnal: 1600 100 USL: 660 100	Cas	e Type: Child Large Blue machine e Namber: 410 e Sare: 12312201 Manuel - 4502006	Teproduc- (bility (AV) Gage RAR 0.00% 5.72% 6.00% 3.16% 0.57% 3.02%
4 Left Edge Width	Measurement Unit An		American State Set	0.00% 3.32%
5 Right Datum 6 Fixture Locator X 7 Fibble Locator Y 8 Final	Repeatability - Equipment Variation (EV) $\label{eq:eq:expectation} \begin{split} \mathcal{B}V &= \overline{R} : K_1 \\ &= 0.00010.116 \end{split}$	Triats K ₁ 1 5.1500 2 5.1500	9%EV = 100[EV /TV] = %2.33% = 5.05% of Spec	0.00% 3.03% 0.00% 15.51% 1.55% 12.76% 1.67% 11.13% Used in this Report
	$\label{eq:approximation} \begin{split} & \overline{\mathrm{Reproduction}}_{Y} - \overline{\mathrm{Approximation}} \left(\mathcal{M} \right) \\ & \mathcal{M}^{U} = \sqrt{(\overline{X} \mathrm{parr} + \overline{K}_{\mathrm{C}})^{2} - (\overline{B} U^{2} \mathrm{d} (m))} \\ & = 0 00002286 \\ & \overline{\mathrm{Approximation}} \end{split}$		9647 - 100[47/77] - 20505 - 1.54% of Spec	
	Repeatability & Reproductibility (GRR) $\label{eq:GRR} URR = \sqrt{ET^2 + AT^2} \\ = 0.00010571$	26116 26911	\$%GRR = 100[GRB (TV] = 94.66% = 5.19% of Spec	
	Part Variation (PV) $\mathcal{P}\mathcal{V} = \mathcal{R}_p \times \mathcal{K}_s$	Parts K ₅ 2 3.6416	36PV = 100 [PV/TV]	

Characteristic Filtering

Reduce on-screen clutter to quickly identify only the most critical features.

Plot Types



Trace Fields

A maximum of 60 additional trace fields can be captured in addition to the measurement data. This allows for more granular filtering when problems occur.

21 CFR Part 11

The control of inspection information as it applies to the medical industry is defined by FDA title 21 Code of Federal Regulations (21 CFR Part 11). QC-CALC's data collection, storage, and reporting adhere to this important standard. This option can be disabled for industries not requiring such strict control.

		Da	ita Integri	ty Repo	rt		Printed on January 27, 200
rolink							
ample	Part.Qcc						
spectic	on data. All changes a user, and reason the cha	ide to the raw QC-CALC re documented and incl nge occurred.	ude the record c to s	reate a record filter to see all changes ma	reduce this rep de for a particu serial number a	ort. For exar	mber, or other condition, pleas mple, you can create a date filt ange of days. Likewise, you ca report for one part. See filterin
spectic	on data All changes a	re documented and incl	ude the record c to s	reate a record filter to see all changes ma earch for a particular	reduce this rep ide for a particu	ort. For exar	mple, you can create a date filt ange of days. Likewise, you ca
nspectic umber,	on data. All changes a user, and reason the cha	re documented and incl nge occurred. Action	ude the record c to s d Feature or	reate a record filter to b see all changes ma earch for a particular ata for more details. Old Value	reduce this rep de for a particu serial number a	ort. For exar lar day or ra and create a User	mple, you can create a date filt ange of days. Likewise, you ca report for one part. See filterir
nspectic umber, Rec	on data. All changes a user, and reason the cha Date Performed	Action Performed	ude the record c to	eate a record filter to base all changes ma earch for a particular ata for more details. Old Value or Action ID	reduce this rep de for a particu serial number a New Value 1.5000	ort. For exar lar day or ra and create a User	mple, you can create a date filt ange of days. Likewise, you ca report for one part. See filterin Reason
Rec 4	Date Date Performed 12/12/2008 1:28:29 PM	Action Performed Dimension 1	ude the record c to	eate a record filter to base all changes ma earch for a particular ata for more details. Old Value or Action ID	reduce this rep de for a particu serial number a New Value 1.5000	ort. For exar lar day or ra ind create a User Bruce Bruce Bruce	nple, you can create a date fill ange of days. Likewise, you ca report for one part. See filterin Reason Bad measurement
Rec 4 9	Date Date Performed 12/12/2008 1:28:29 PM 12/17/2008 1:29:01 PM	Action Performed Dimension 1 NumFactor 1	ude the record c to s d Feature or Document Location Feature 1 Cavity	reate a record filter to see all changes ma earch for a particular ata for more details. Old Value or Action ID 1.4986	New Value 1.5000 2	ort. For exar lar day or ra and create a User Bruce Bruce Bruce Bruce	mple, you can create a date fift ange of days. Likewise, you ca report for one part. See filterin Reason Bad measurement Remeasured Part

Add Pictures to Each Characteristic

A picture can be added to each characteristic to give more meaning to the plot data.



Please download a 30-day trial version from our website and try it out! Prolink Corporation • 860.659.5928 • www.prolinksoftware.com



Introduction

QC-CALC SPC is a complete SPC package that analyzes the data collected by QC-CALC Real-Time. The wide variety of charts and reports available in QC-CALC SPC allows close monitoring of the manufacturing process in order to stay in control. In seconds, QC-CALC SPC gives a precise picture of how the production line is performing with easy-to-use menus.

Key Benefits

- Record and Characteristic filtering
- Control charts
- Process capability charts
- Attribute charts
- Ability to print to PDF and email reports
- Built-in report designer
- Remote Real-Time monitoring
- Multiple database grouping
- 21 CFR Part 11 compliance
- Built-in password protection

Reporting

Reporting in QC-CALC SPC analyzes the data and prints the charts to a printer, print preview, or to a file. The following report types are available:

Control Charts

- Xbar & Range
- Xbar & Sigma
- Median & Range
- Individual & Range

Process Charts

- Histogram Analysis
- Probability Plots
- Pareto Analysis

Attribute Charts

- P Chart Np Chart
- C Chart • U Chart

Miscellaneous Reports

- Statistical Summary
- Raw Data
- First Article
- Non-Conformance
- Gage R&R (Range & ANOVA)
 - 21 CFR Part 11 Audit Report

• Individual & Moving Range

• Moving Average & Range

• Bivariate Analysis Report

• Process Capability (Cpk)

Correlation & Regression

• Raw Data w/ Outlier Detect

Record Filtering

Quickly display and report on the data needed at the moment.


Characteristic Filtering

Reduce on-screen clutter to quickly identify only the most critical characteristics.

21 CFR Part 11 Compliance

The features that make QC-CALC so flexible can be controlled using the built-in Administrative Tool to guarantee total control of changes. This system includes an audit report showing all password protected changes.

ne Real-Time Subgroup Size Out of Control Features (3) 2 Hole Position	e: 1 SPC Subgroup Size:							
Out of Control Festures (3) 2 Hole Position								
	(4) Line Leng	sth •••••••••√**•^√/						
M. M.	ma wi							
*M. M. M	MAN MAN	·····						
A # 71124 . A .	A MATHAN .							
	Sample100.QCC SPC Subgroup Size: 5 Real-Time Subgroup Size: 1 File Path: C:\Priofink\QC-CALC 3.4 QC\Data\							
		(4) 4Dimension number 4	(5) 5Dimension number 5	(6) 6Dimension				
2.4745	3.44	4.459	5.5275	6.45				
2.5073	3.57	4.529	5.4885	6.44				
2.5448	3.55	4.466	5.5917	6.56				
2,4508	3.50	4.478	5.5824	6.39				
2.5413	3.49	4,447	5.3902	6.55				
2.2876	3.44	4.558	5.5150	6.51				
2,5530	3.46	4.482	5.5599	6.47				
2.4974	3.48	4.385	5.4725	6.42				
2.4432	3.44	4.552	5.5192	6.51				
2.4710	3.49	4.515	5.5141	6.48				
2.4977	3.47	4.456	5.4921	6.50				
2.4254	3.44	4.496	5.4702	6.57				
2.4075	3.44	4.514	5.5160	6.49				
2.4411	3.60	4.544	5.4669	6.45				
2.5515	3.51	4.536	5.5184	6.52				
2.4561	3.53	4.455	5.5246	6.61				
2.6040	3.46	4.543	5.4463	6.50				
2.5311	3.50	4.492	5.4545	6.60				
	3.48	4.458	5.4803	6.51				
2.4233								
2.4603	3.41	4.581	5.4632	6.62				
2.4603 2.4109	0.50	4.505	0.0720	0.01				
2.4603 2.4109 2.4767	0.50 3.61	4.505 4.457	5.0725 5.5054	0.51 6.48				
2.4603 2.4109	0.50	4.505	0.0720	0.01				
	24745 25073 25448 24508 24508 24513 24513 24514 24514 24514 24514 24515 24515 24515 24515 24515 24515	24745 2.477 2.577 3.57 2.5448 3.55 2.4540 3.59 2.5413 3.49 2.2576 3.44 2.4576 3.44 2.477 3.44 2.4417 3.44 2.4417 3.44 2.4417 3.44 2.4417 3.44 2.4417 3.44 2.4417 3.44 2.4417 3.44 2.4417 3.44 2.4411 3.69 2.5515 3.51 2.6461 3.53 2.6464 3.54	2 4745 3.44 4.459 2.577 3.57 4.529 2.5448 3.55 4.680 2.6509 3.59 4.478 2.513 3.49 4.477 2.2513 3.49 4.473 2.2530 3.40 4.653 2.4719 3.44 4.553 2.4719 3.44 4.551 2.4719 3.44 4.551 2.4719 3.47 4.456 2.4717 3.47 4.466 2.4755 3.47 4.466 2.4254 3.47 4.466 2.4255 3.51 4.538 2.4411 3.60 4.554 2.4551 3.51 4.558 2.4551 3.51 4.555 2.4691 3.53 4.455 2.4691 3.53 4.455	25073 3.57 4.539 5.468 2.5448 3.55 4.468 5.5917 2.4509 3.50 4.478 5.5024 2.5413 3.40 4.447 5.5024 2.2870 3.40 4.502 5.5190 2.470 3.40 4.502 5.5190 2.470 3.40 4.552 5.5192 2.4710 3.40 4.552 5.5192 2.4717 3.47 4.456 5.5141 2.4977 3.47 4.456 5.4725 2.4517 3.44 4.552 5.5142 2.4517 3.44 4.569 5.4721 2.4517 3.44 4.569 5.4721 2.4517 3.64 4.469 5.4722 2.4517 3.64 4.450 5.4721 2.451 3.69 4.543 5.4769 2.5515 3.514 4.556 5.5246 2.469 3.51 4.545 5.5461 2.649				





Grouping

Create a concise summary report by opening multiple files simultaneously across different inspection equipment. Each file can be displayed in a spreadsheet or as plots, similar to QC-CALC Real-Time.




Monitoring

As the CMM runs, QC-CALC Real-Time is updating its live screen while QC-CALC SPC displays the same data in another location (remote office, machining center, etc...). Monitor a single file, a group of files, or the inspection machine itself and see the data in either live plots or in grid form.

Tabs in Plot View

When using the Plot View option, multiple tabs are available to quickly switch between the dynamic Characteristic Filters.



Multiple Characteristic Reporting

Due to the large number of characteristics that can be saved in each file a secondary option is available for the reports within QC-CALC SPC. Using the Multiple Plots option provides a brief overview of the statistics for each characteristic along with the corresponding graph for that report type.



For more information, contact us at sales@rfminc.net

Resources for Manufacturing, Inc. • 3000 South Tech Blvd, Miamisburg, OH 45342 • (937) 436-4699